

TOYOTA LandCruiser 200 Series**All V8s / 3 Battery**

Use this guide to assist in the installation of the Western Filters, Fuel Manager Pre-Filter Kit. This kit will only fit the stated vehicle. Although these kits are aimed at DIY enthusiasts, we suggest the inexperienced organise a mechanic to carry out the installation.

If the LC 70 Series has a second battery mounted behind the original fuel filter (between filter and firewall), the alternative 70 Series Landcruiser Kit FM616DPK should be used.

BEFORE STARTING: PLEASE READ THIS IMPORTANT INFORMATION

- Ensure the engine bay is clean and free from contaminants.
- The Fuel Manager unit has arrows which indicate flow located under the ports.
- Install all fittings & plugs into the filter assembly using a suitable thread paste such as Permalock Thread Sealant.

**** Kit contents may change due to refinement or parts availability.**

Fitting Instructions:

1. Remove inlet hose from original filter.
2. Remove the 2x retaining nuts on top of the factory filter.
3. Install the Vehicle Specific Bracket on top of the original filter housing and refit the retaining nuts.
4. Install all fittings and plugs into the filter assembly using suitable thread paste sealant.
5. Mount Fuel Manager filter assembly on to the bracket.
6. Connect the inlet side of the final original filter to the outlet of the Fuel Manager filter.
7. Fit the supply fuel line to the inlet of the Fuel Manager.
8. Reconnect outlet pipe of the factory filter to the inlet of the common rail supply pump.
9. Ensure all fuel lines are suitably secured.
10. Prime the system using the hand primer on the factory filter.
When the primer goes firm, the engine is ready to start.

FM615DPK**FUELMANAGER[®]**
FITTING INSTRUCTIONS**FM615DPK Kit Contains:**

- :: Fuel Manager 100 30 Micron Filter Assy
- :: Vehicle Specific Bracket
- :: 1mtr Fuel Line Rubber
- :: Bolts, Washers & Nyloc Nuts
- :: 1/2" Straight Barb Fittings
- :: Blanking Plugs
- :: Hose Clamps