



- Ensure the engine bay is clean and free from contaminants.
- □ The Fuel Manager unit has arrows which indicate flow located under the ports.
- Install all fittings and plugs into the filter assembly using a suitable thread paste such as Permatex Thread Sealant 592914.

Kit Part No: FM609DPK

INSTRUCTIONS

- 1. The new bracket will mount on the passenger side mud guard fire wall, under the windscreen motor.
- 2. Using the existing hole in the mud guard loosely mount the bracket using an 8mm bolt.
- 3. Using teck screws, push bracket firmly against fire wall and screw bracket to lip in firewall.
- 4. Tighten bottom mounting bolt.
- 5. Install all fittings and plugs into filter assembly using suitable thread paste sealant such as Threebond 1110B.
- 6. Mount Fuel Manager filter assembly to mounting bracket.
- 7. Remove the flexible fuel hose from inlet side of the original filter and connect the hose and hose clamp supplied to the inlet side of the Fuel Manager filter.
- 8. Connect outlet pipe of the Fuel Manager filter to the inlet pipe of the original filter using hose and clamps supplied. Run all hoses along the firewall and secure.
- 9. Prime the system using the hand primer on the factory filter. When the primer goes firm, the engine is ready to start.



Pre-Filter Fitting Instructions

Mazda BT50 & Ford Ranger 3.0 Ltr



KIT CONTENTS

- 1. Fuel Manager 30 micron Filtration Unit
- 2. Mounting Bolts, Washers and Nyloc Nuts
- 3. Spare 30 Micron Replacement Filter
- 4. 3mtr of 8mm Quality Fuel Hose
- 5. Direction Plus Filter Bracket
- 6. 8mm Straight Barb Fittings
- 7. Blanking Plugs
- 8. Hose Clamps



P: (02) 9831-1715 | F: (02) 9671-2212 | E: enquiries@westernfilters.com.au | W: www.westernfilters.net.au 45 Forge St, Blacktown NSW 2148 | Mon-Fri: 7:00am – 5pm / Sat: 7:00am – 12pm













